

Brake Rotor Installation Guide

- 1) Please remove the 12 screws from the rotor/ mounting bell assembly.
- 2) Please mount the disc/ mounting bell assembly onto the hub using the 12 screws provided.
- 3) Please make ABCD shown in figure below have the same distance as each other by using calibrated scale. (The tolerance can not exceed 0.05mm)
- 4) Please tighten the 12 screws and torque them to 14-17 NM for M6 bolts and 20NM for M8 bolts.
- 5) Verify if the tolerance of ABCD is within 0.05mm.
- 6) The vibration of the vehicle will occur while the car is moving if the tolerance exceeds 0.05mm.

